



Tech Info Library

AppleWorks IIe: Connecting a NEC 3510 letter quality printer

Revised: 3/3/86
Security: Everyone

AppleWorks IIe: Connecting a NEC 3510 letter quality printer

=====

A. Apple IIe

1. Super Serial Interface Card settings:

	1	2	3	4	5	6	7		1	2	3	4	5	6	7
ON				X	X	X		ON	X	X					X
SW1								SW2							
OFF	X	X	X		X			OFF		X	X	X	X		
	1	2	3	4	5	6	7		1	2	3	4	5	6	7

-- Jumper block points to TERMINAL

2. AppleWorks settings

- a. Carriage: 11"
- b. Linefeed after carriage return: YES
- c. Underlining: The NEC 3510 LQP makes an underlines by printing the character, backspacing one character, and printing the underline.

d. Special Codes

-- Check the printer manual.

Begin End

- 1. Boldface: Esc * Carriage Return
- 2. Underline: Esc - Esc '
- 3. Superscript: Esc ; Esc :
- 4. Subscript: Esc : Esc ;

5. Proportional Spacing 1: Esc H Esc I

B. Cabling

Super Serial	
Interface Card	NEC 3510
DB-25	DB-25
2	2
3	3
7	7
19	19

C. NEC 3510

1. Switch settings

a. Front panel

- 1 - Off
- 2 - Off
- 3 - On
- 4 - Off
- 5 - On
- 6 - Off
- 7 - Off
- 8 - Off

b. Back panel

- 1 - Off
- 2 - Off
- 3 - Off
- 4 - Off

-- 9600 baud, no parity, 8 data bits, 1 stop bit

Apple Technical Communications

Tech Info Library Article Number:1783