



# Tech Info Library

## Apple IIGS: Troubleshooting Out of RAM 04 Message

Revised: 9/5/91  
Security: Everyone

Apple IIGS: Troubleshooting "Out of RAM 04" Message

=====

Article Created: 14 May 1991  
Article Last Reviewed: 23 May 1991  
Article Last Updated:

TOPIC -----

How much memory does an Apple IIGS need to run System v5.0.2?

I was told 768K, but when I tried to boot a system disk on an Apple IIGS with an expansion board installed, and with the entire first bank populated (top line of card full, top jumper not connected, bottom one connected), I got an "out of RAM" 04 message on the Apple IIGS.

I want to run GS/OS 5.0.2 over the net from a server, but if it can't even boot standalone, what do I need to run the net? Is 768K enough? Isn't that what I have? (256 + 512 (logic + add on))

DISCUSSION -----

GS/OS should boot on a standalone Apple IIGS with 512K of RAM. If network services are going to be used, 768K is required.

Check to see if you have a RAM disk created in the Control Panel. Perhaps the RAM on the logic board or the memory expansion card is faulty; try running diagnostics. The card could be misidentifying the amount of RAM (because the jumpers aren't read correctly by the card even though they are set correctly).

Copyright 1991, Apple Computer, Inc.

Tech Info Library Article Number:8150