

COPYRIGHTS WARNING

Orange Micro Inc. reserves all rights in the software incorporated in the PROM or EPROM in the ProGrappler and in the Operators Manual. Any infringement of those copyrights will be prosecuted to the fullest extent allowed by the law.

(German)

HINWEIS

Orange Micro Inc. reserviert alle Rechte hinsichtlich in der PROM oder EPROM in der ProGrappler und der Gebrauchtsanweisung erwaehnten Software. Verstoesse gegen die copyrights jeglicher Art werden gerichtlich verfolgt unter vollster Ausschoepfung des

(French)

andwendbaren Gesetzes.

AVIS

Orange Micro Inc. se réserve tous droits du programme controlant les differentes operations du PROM ou EPROM du ProGrappler ainsi que celles decrites dans le Manuel d'utilisation du systeme. Tout violateur de ces copyrights wera poursuivi dans toute la mesure fixee par

(Spanish)

la loi.

ADVERTENCIA

Orange Micro Inc. se reserva todos los derechos de programmacion incorporada en el PROM o EPROM en el ProGrappler y en el Manual de la Operadora. La violacion de estos derechos de copia ocasionara la mayor prosecucion permitida por la lev.

Trademarks

Apple II, Apple II+, Apple IIe, and Apple IIGS are trademarks of Apple Computer Inc.



TABLE OF CONTENTS

GETTING STARTED	
Introduction	
What's in the Package3	į
Compatibility Notes	
Computer Compatibility	+
Software Compatibility	ŀ
Printer Compatibility5	í
Installing the ProGrappler 6	
DIP SWITCH SETTINGS7	,
Apple IIGS Installation & Setup	ĺ
Apple IIe and Apple II+ Installation Tests	
If You Are Using Apple DOS	ĺ
If You Are Using CP/M11	
If You Have Trouble11	
HOW TO USE THE PROGRAPPLER11	
Introduction11	
SECTION A: PROGRAPPLER AS A CLASSIC12	,
DESK ACCESSORY (SCREEN SHOT FEATURE)	
To Do a Screen Shot	
SECTION B: USING PULL- DOWN MENUS	
" ₡ " Menu15	
About ProGrappler15	
Troubleshooting15	
"File" Menu	
Set Values	
Set Values	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16 Page Set-Up 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16 Page Set-Up 16 "Size" Menu 17 "Style" Menu 17	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16 Page Set-Up 16 "Size" Menu 17 "Style" Menu 17 Draft 17	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16 Page Set-Up. 16 "Size" Menu 17 "Style" Menu 17 Draft 17 Double-Strike 17	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16 Page Set-Up 16 "Size" Menu 17 "Style" Menu 17 Draft 17	
Set Values 15 Text Dump 80 16 Text Dump 40 16 Text Dump 1 & 2 16 Form Feed 16 Print Test 16 Quit 16 "Format" Menu 16 Page Set-Up. 16 "Size" Menu 17 "Style" Menu 17 Draft 17 Double-Strike 17	

GETTING STARTED

Proportional	18
Underline	
Italic	
Sub-Script	
Super-Script	
"Graphic" Menu	18
Print	18
Screen Type	18
Invert	
Rotate	
Color	
Hi-Density	
Aspect Ratio	
Page Position	
Enlargement	
Window Set	20
SECTION C: KEYBOARD COMMANDS	21
Using Control-i Commands	22
Using "PRINT" Statements	22
SECTION D: PROGRAPPLER COMMANDS	
General Commands	
Text Formatting and Style Commands	
Graphics Command	26
Default Parameters	
TROUBLESHOOTING	28
APPENDIX A: RUNNING TEST PROGRAMS	
APPENDIX C: LOADING DUAL HI-RES PAGES	33
APPENDIX C: LOADING BOAL HI-RES PAGES	34
APPENDIX E: ROUTINES FOR ADVANCED	
PROGRAMMERS	
APPENDIX F: TRANSPARENT MODE	26
APPENDIX G: MEMORY LOCATIONS AND	37
CUSTOM DRIVERS	
APPENDIX H: PROGRAPPLER PIN	

Introduction

Congratulations! You now own the ProGrappler, the latest version of the best selling, most copied printer interface in the entire Apple world. The ProGrappler has been updated to provide maximum support for the Apple IIGS, Apple's latest innovation, and contains powerful new features for Apple IIe users as well. The ProGrappler still provides all the well-known

users as well. The ProGrappler still provides all the well-known benefits of its predicessors for Apple II and II+ owners.

Perhaps most convenient of the new features is the ProGrappler-IIGS Screen-Shot utility, allowing your to print virtually any screen from any program, without resetting your Apple. Once the ProGrappler is installed as a IIGS desk accessory, you can access it at any time through the IIGS "Control Panel," as long as your software allows it. When your printing is done, you just "quit" the ProGrappler and exit back to your application in progress. For more on this powerful IIGS feature, see page 12.

Maximizing the Power of Your System

The ProGrappler will serve as a parallel printer interface in any Apple II, II+, IIe or IIGS computer, but the more powerful your Apple, the more power the ProGrappler can provide. As a result, this manual has been written in sections which reference the systems to which they apply. If you do not see your system listed at the beginning of a section, the features described in that section are not available to you.

What's in the Package

You should find the following items in the ProGrappler package:

- ProGrappler Interface Card
- 2. Printer Cable

What Else You Need

To complete installation, you need the following:

- A screwdriver
- 2. A complete Apple II, II+, IIe or IIGS system
- 3. A Parallel printer with paper, ribbon, etc.

NOTE: If you are using an Apple IIe mouse, you must also have an Enhanced Apple IIe and and 80 column card for proper operation of the mouse and ProGrappler menus.

ASSIGNMENTS.................

Compatibility Notes

The ProGrappler is designed to work in a wide range of Apple II applications. However, certain limitations do exist, due to the many configurations possible with this versatile system.

Computer Compatibility

The ProGrappler will work with all Apple II slotted computers. It provides basic screen dump capability to all models, and provides additional user interface options on the Apple IIe and IIGS, including pull-down menus. On the Apple IIGS, the ProGrappler firmware installs as a Classic Desk Accessory (CDA), allowing you to print from almost any application without quitting your program. Sections of this manual describing ProGrappler features are preceded by a list of the Apple systems supporting those features.

Software Compatibility

The ProGrappler is generally compatible with Applesoft BASIC, DOS 3.3, ProDOS, Integer BASIC, PASCAL and CP/M. PASCAL 1.0 and CP/M require specific procedures for ProGrappler tabs and right margins. See "Troubleshooting" on page 30 for details.

To fully utilize the ProGrappler, software must by able to recognize its standard code set. The ProGrappler is recognized by thousands of software titles, but not by all of them. Check your software manual for references to selecting a printer card. Generally, ProGrappler, Grappler+ or Grappler selections will work. Other selections which often work include Orange Interface, Epson APL, Dumpling, Printerface and Graphicard.

APPLE IIGS SOFTWARE NOTE: Many new packages for the Apple IIGS support only the ImageWriter II printer at this time. In their present form, they cannot support the ProGrappler or parallel printers. Many of these may be adapted through the simple addition of drivers for your printer and ProGrappler card, which are still under development as of this manual writing. Ask your dealer for details, or contact Orange Micro.

PASCAL-CP/M NOTE: Whenever booting up a PASCAL or CP/M program, your printer must be ON and ON-LINE, or the system will hang up.

Printer Compatibility

As a physical link between your printer and your Apple, the ProGrappler is compatible with virtually all parallel printers following the Centronics parallel standard. As of this manual's writing, no currently produced parallel printers are known to use another standard, except Tandy printers.

For graphic screen dumps and other special commands contained within the ProGrappler, compatibility is only slightly more limited. The ProGrappler supports several dozen popular parallel printers, listed in the DIP switch table on page 7. If your printer is not listed, try the various Epson settings, as this is a popular standard. (Be sure to turn power off and to follow the installation procedures precisely each time the switches are changed.) Next contact your dealer or printer manufacturer. Your printer must use codes compatible with one of the printers listed in order to use the ProGrappler's built-in features.


Installing the ProGrappler

To install the ProGrappler board into your Apple computer you will need a screwdriver. Then follow the steps shown below:

- POWER OFF. Unplug your computer, printer and monitor from power outlets before doing anything. Do not install or remove a board when power is applied. This could damage the board and/or the computer.
- 2. Remove the cover from your computer. This is the large, flat part of your system on which the monitor sits.
- Next, touch any metal part of the back panel of the Apple with your finger to discharge any static electricity you may have built up so far. This protects any sensitive components on the ProGrappler from damage due to high static voltages.
- 4. Set the ProGrappler DIP switches:

Locate your printer model in table 1 on the following page. If you do not see it listed, try settings for any other models by the same manufacturer. If your manufacturer is not shown, try the Epson MX series setting, as Epson is a widely accepted standard. If this does not work, contact your dealer or printer manufacturer to determine compatibility with any of the listed printers. Your printer must be compatible with one of the listed ProGrappler models to be supported by the ProGrappler special printing features.

Refer to figure 1, which shows the layout of the ProGrappler board. The switches are located at the top left of the card, labeled 1 through 6. Using a toothpick, pencil, paper clip or pen, set these switches according to the settings indicated in table one.



The on/off positions are indicated on the left side of the DIP Switches. Note that the DIP Switches are always pressed down to select the desired position. For example: for ON, press down on the ON side. For OFF, press down on the OFF side.

on the ON side. For OFF, press down on the OFF side.						
		SWI	тсн	ES		
Printer and Model	#1	#2	#3	#4	#5	#6
BROTHER						
1109, 1509, TWNWRITER 5	OFF	OFF	ON	OH-	OH-	OH-
Citizen						
MSP 10, MSP 15, MSP 20, MSP 25	OFF	a N	OFF	OFF	OFF	OFF
0.17011						
C. ITOH ProWriter 310/315	ON.	ON	Œ	Œ	Œ	Œ
ProWriter 8510		OFF				
Color 310		ON				
Colors IO	ω ι	۵ı	α ι	α ι	σ ι	~ 1
EPSON						
RX, LX, LQ, FX, DX Series, SQ 2000, HS 80		ON				
Color Models		ON				
MX Series and Compatibles	ON	ON	OH-	ON	ĊΝ	OH-
Hewlett Packard						
ThinkJet (Epson Mode)	ON	ON	ОFF	ON	ОFF	OFF
NEC						
Pinwriter P2, P3, and P5	ΟFF	OFF	ON	ON	OFF	OFF
Color Models (CP2, CP3)		OFF				
Okidata	~ ⊤	ON	~ 1	~ ∓	Œ	Œ
190, 290 Series, 2410		OFF				
80, 90 Series		ON ON				
Color Models (290 Series) Okimate 10 and 20		ON				
Note that all Okidata 80 series printers	σ.	۵ı	۵ı	~ 1	~ ·	۵.
except the Model 84 are supported.						
enage the read of all supported						
PANASONIC						
KX-P1080, KX-P1090, KX-P1091, KX-P1092						
KX-P1592	ОN	ON	ОN	OFF	OFF	OFF
Star Micronics						
SG, SR, SD Series	ON	OFF	ON	OFF	OFF	OFF
,,						
Toshiba						
P-321, P-341, P-350, P-351, P-1341, P-1350,	~	~,	~	. ~.	~_	~_

Table 1. ProGrappler DIP Switch settings

P-1351

Color Model (P-351C)

Transparent Mode (Letter Quality)

OFF ON OFF ON OFF OFF

OFF ON OFF ON OFF ON

OFF OFF OFF OFF

5. Moving back to the Apple, locate slot #1¹. Figure 2 shows the inside of an Apple IIGS, but all Apple IIs have similar slot layout. Looking into the Apple from the front, you will see the slots arranged in a row along the back of the Apple. These slots are labeled one of two ways: either 0 through 7, or 1 through 7 with an auxiliary slot closer to the front of the machine. It is strongly recommended that you use slot #1 for the ProGrappler, as most of your software, as well as the IIGS desk accessory menu, expects to see the printer at that location. Other slots may be used (except Ø), but you will have to modify or reconfigure many of your programs. Remove any cutouts or plugs to clear the appropriate corresponding opening at the rear of the Apple II.




Figure 2.

- 6. FCC regulations require that all computing equipment be grounded to limit interference with television and other radio frequency transmissions. These regulations apply only to later model computing equipment, including the Apple IIe enhanced and the Apple IIGS. Earlier models were not designed to properly limit interference. Locate the ProGrappler printer cable, and notice the ground clamp near the small end of the cable. Using a screwdriver, loosen the screw running parallel to the cable. Pass the small end of the ProGrappler printer cable in through the appropriate opening in the Apple. Slide the clamp up inside the cutout such that the screw fits into the notch. Tighten the screw with the screwdriver. In certain Apple II models, this clamp may not
 - We assume that you inserted the ProGrappler into Slot # 1. If you inserted the ProGrappler into a different slot, be sure to remember that slot number. Substitute that slot number whenever you see the command "PR # 1"; for example, "PR#2" for Slot#2.

small washer may be used to improve this contact.

- 7. Examining the connector at the small end of the cable, now inside your Apple, you will see that one side of the connector has a wire occupying each position, and the other has only a few wires in total. The "full" side should be facing out from the ProGrappler card when the cable is attached. Making sure that the connectors are lined up and centered, press the cable connector onto the ProGrappler card.
- To install the ProGrappler, position its edge connector (see figure 1) over slot #1 and press firmly down on the card, rocking it gently until it is completely and solidly seated in the slot.
- Replace the cover on your computer.
 Most printers are factory set for compatibility with the ProGrappler. This requires that 8 data bits are being used, as opposed to 7, and no linefeeds should be added by the printer. These settings are determined by switches INSIDE YOUR PRINTER. Consult your printer manual for more

details. Plug the printer end of the ProGrappler cable into the

printer.

11. Now reattach power to your computer, monitor and printer.

You are now ready to let your Apple know that a ProGrappler has been installed. Refer to the following "Installation Test and Set-Up" section appropriate for your computer model.

Apple IIGS Installation Test and Set-Up

The IIGS Control Panel

The Apple IIGS needs to know that a printer card is to be used instead of the serial port at the back of the computer. Use the following procedure.

- 1. Insert the IIGS system disk into the drive.
- 2 Turn on power, booting the system disk
- When the drive stops spinning, press CONTROL-G-ESC simultaneously. This will bring up the Classic Desk Accessory menu.
- Using the UP/DOWN arrow keys, select CONTROL PANEL and hit (Return).
- 5. Using the arrow keys, select SLOTS and press (Return).
- 6. With the arrow keys, select SLOT 1 (unless the ProGrappler is installed in another slot).
 - Then use the LEFT/RIGHT arrow keys to change PRINTER PORT to read YOUR CARD and press (Return).
- Use UP/DOWN arrows to select QUIT from the Control Panel menu, and then the Desk Accessory menu.
- Turn OFF the computer and wait about 30 seconds. When you turn it back on, it will remember the settings you have made.

provide sufficient contact with the computer's metal lining. A

Run the Apple IIe/DOS test routine found below, using the system disk in place of the Apple DOS disk.

The Apple IIGS and Print Drivers

Newer software programs designed specifically for the Apple IIGS may use a new printing format not found in earlier Apple II software. Generally, software which displays visible folders on the "Desktop" before booting will be of this variety, but this is not an absolute rule. This later software may require the addition of a special driver in order to recognize or use any printer card or the printer attached to it. This is IN ADDITION TO the control panel procedure performed above. Contact your dealer, Orange Micro, or the publisher of your software for additional information regarding the availability of print drivers on the Apple IIGS.

The ProGrappler also has a full set of graphics and text printing features that can be installed as a seperate Classic Desk Accessory. This still requires that the control panel installation procedure be performed. A full discussion of the ProGrappler as a IIGS Desk Accessory is found on page 12.

APPLE IIe and APPLE II+ Installation Tests

If You Are Using Apple DOS:

- Insert an Apple DOS diskette all the way into your Disk Drive and close the door.
 - **NOTE**: Do not insert a diskette while the disk drive is running. If the red light on the disk drive is lit, turn off the power to your computer, then insert the diskette.
- After double-checking everything, you may now turn on your computer, monitor and printer. This automatically starts your program.
- Press CONTROL-RESET simultaneously, then press (Return). This resets your system.
- 4. When you see the "]" prompt on the screen, type PR#1, then hit (Return) several times. (Remember to substitute the correct slot number here if the ProGrappler is not plugged into Slot #1.) Your printer should be printing an "]" each time you hit the (Return) key, after a few seconds delay.
- 5. Type PR#Ø, then press (Return).
- 6. You may now place any program in the drive and type PR#6 and press (Return) to start the program.

If You Are Using CP/M:

CP/M is NOT on your standard Apple system disk, but some applications use this Operating System. If you are using CP/M, the ProGrappler *must* be installed in Slot #1. If it is not, go back to the beginning of this section (Installing The ProGrappler) and re-install the ProGrappler into Slot #1 at this time. (Also, when using CP/M and Wordstar, see Appendix F: Transparent Mode.)

- Make sure that power is off on the computer, monitor and printer.
- Insert the CP/M diskette all the way into the Disk Drive and close the drive door.
- Turn on the computer, monitor and printer. This automatically starts the program.

NOTE: Be sure to turn on your printer first and make sure it is "on-line" whenever booting up PASCAL or CP/M.

- When you see the "A>" prompt, enter the Control-P command. That is: hold down the Control key and press the P key, then release both keys.
- 5. Now hit the Return key several times. The printer should print an "A>" each time you press the key.

If You Have Trouble:

Double-check everything in the last section. If you cannot find the problem, check for the following:

- a) Printer power cord is plugged in
- b) Printer power is on
- c) Printer cable is solidly attached
- d) Printer "Select" is on
- e) Paper is in the printer

HOW TO USE THE PROGRAPPLER

<u>Introduction</u>

In addition to serving as a standard parallel printer interface, the ProGrappler provides dozens of powerful features for the printing and formatting of graphics and text, including printing of color graphics directly from the screen on selected color printers. These features can be used in a number of different ways, and what system you have will determine the options available to you.

This section of the manual is divided into four sections. Part

A, using the ProGrappler as a Desk Accessory, only applies to
users of the Apple IIGS. Part B covers the use and functionality of the ProGrappler's pull-down menus, and applies to all
Apple IIGS and IIe enhanced users. Regular Apple IIe users
may also use pull-down menus, but they may not appear as expected due to the characters available on that computer. Part

C covers the use of the keyboard to enter ProGrappler commands, and this is valid on all Apple IIs, although certain commands may work only on later models. Part D recaps all the ProGrappler commands, showing both the CONTROL-I keyboard command and the BASIC equivalent. BASIC commands will be used when including ProGrappler commands within a program.

SECTION A THE PROGRAPPLER AS A CLASSIC DESK ACCESSORY (SCREEN SHOT FEATURE) (APPLE IIGS ONLY)

The many screen printing functions of the ProGrappler are available through the Classic Desk Accessory (CDA) menu of the Apple IIGS (remember where you specified "Your Card" in installation?). When active as a CDA, the ProGrappler allows you to print any screen from virtually any software that allows the use of CDAs. The ProGrappler CDA will bring up the pull-down menus described in sections B and D. If you are using a 5-1/4" drive, or are NOT using the IIGS system disk, use the "Apple IIe and II+ Installation Test" for Apple DOS as it appears on page 10, starting with step 3, to install the ProGrappler CDA. You may do this at any time while using Apple IIe/II+ software. This method will work until you start a program that "re-boots" the system. In these cases the ProGrappler CDA is not accessible.

- 1. The ProGrappler must be installed as a CDA at the beginning of each computing session. Some software may contain drivers installing the ProGrappler automatically, but many will require installation with each power-up. Insert the IIGS system disk into drive 1 and turn on power. Select and open BASIC from the launcher menu. When the cursor appears, type PR#1 and press (Return). The printer will respond with a carriage return if properly installed. If there is no response see "Installation Tests" on page 9. Type PR#0 and press (Return), then type BYE and press (Return). The Apple IIGS launcher will appear.
- 2. Press CONTROL-G-ESC to bring up the CDA menu, which will display the ProGrappler as a selection.
- 3. Using the UP/DOWN arrows, select ProGrappler and press return. The ProGrappler menus will appear, with the printer selected by your ProGrappler displayed in the right top corner. (Refer to DIP switch settings on page 7.) The next section, "Using Pull-Down Menus," will tell you how to use this screen. For now, press ESC to return to the CDA menu.
- 4. Select QUIT from the CDA menu. This will return you to the screen visible immediately prior to entering the CDA menu.

IMPORTANT NOTE: If you reset your Apple IIGS at any point, by typing a CONTROL-C-RESET, starting a self-booting program, or turning the computer off, you must repeat the above procedure before using the ProGrappler CDA. You will have to turn off the IIGS for about 30 seconds before starting Step 1.

- Remove the System Disk from the drive and insert any Apple IIGS application disk. Press (Return). The launcher will now display the files available on the new disk. Using the mouse or the arrow keys, select and launch the application.
- 6. TO DO A SCREEN SHOT. When the program displays a desired screen, press CONTROL-G-ESC to open the CDA menu. If ProGrappler is shown, then installation was successful, and your software properly supports the Apple IIGS CDA routines. Select QUIT to return to your application, or perform a screen dump by following the menu procedures described in the next section.

SECTION B PROGRAPPLER PULL-DOWN MENUS (Apple IIGS, Apple IIe enhanced and Apple IIe² w/80 column cards only)

Pull down menus give you all the functions of the ProGrappler on-screen. You don't need to remember anything except how to access the menu bar. The rest is spelled out in plain english, right on the screen.

The procedure for executing a command from the menus is straightforward:

- 1. Access the menu bar
- 2. Pull down a menu
- 3. Select a menu item
- 4. Set a menu item
- 5. Close the menu
- 6. Close the menu bar

A "Dialog Box" may appear when an item is selected. Dialog Box use is the same as Menu use.

The menu bar may be accessed two ways. The first is through the Apple IIGS CDA menu as described in section A. The other is through a Control-I command, which will be

²The original Apple IIe can be used, but inverse characters will be displayed in place of mouse text.

Section B: Pull-Down Menus, continued.

discussed futher in the next section, "Using Keyboard Commands." Control-I commands can only be entered from BASIC, so you must leave your program first. To do this, press CONTROL and RESET (the gray key above the keyboard on the IIGS) simultaneously when the graphics screen you wish to print is displayed. This will cause your program to stop running and will give you an empty screen with a cursor in the upper left corner. The graphic is no longer displayed, but is still retained in screen memory within the Apple.

Next, type PR#1 and press Return. The printer will respond with a carriage return and will print the single prompt. You will now enter a CONTROL-I FM, as follows:

- 1. Hold down the CONTROL key and press I.
- 2. Release I and then release CONTROL.
- Type FM without spaces, and press Return.
 The ProGrappler menu bar will appear on the screen.

NOTE: To use a mouse, you must have the following: an enhanced Apple IIe or an Apple IIGS. The Apple II+ does not support a mouse interface.

Specific Use of Menus

		_	
1.	To <i>Select</i> a menu	<u>Using Keyboard</u> Use arrow keys	<u>Using Mouse</u> Point mouse
		or	
		type SHIFT-# ³	
2.	To Pull down menu	Press (Return)	Click and Hold
3.	Select a menu item	Use arrow keys	Point mouse
		or	while holding
		type SHIFT-#	
4.	Set menu item	Press (Return)	Release mouse

If a dialog box appears after step 4:

Select item with arrow keys, SHIFT-# or mouse Open or set items with (Return) or mouse click Enter specific responses with the keyboard Close dialog box by pressing ESC or clicking on OK box

5.	Close menu	Press ESC	(No action
6.	Leave menu bar	Press ESC	req'd) Select QUIT under FILE
			menu

³ You may also select a menu by entering (Shift-#), where "#" is the number or character in front of the desired menu item.

Section B: Pull-Down Menus, continued.

A Pull-Down Menu

This is what the menu bar looks like with an open menu. The numbers preceding the names are used in the SHIFT-# commands. Three dots (...) indicate that a dialog box will appear with that selection. A check mark will precede already selected items.

1. 🖒 2. File 3. Format 4. Size 5. Style 6. Graphics

 Set Values
2. Text Dump 80
3. Text Dump 40
4. Text Dump 1&2
5. Form Feed
6. Print Test
7. Ouit

1." 🗗 " Menu

- About ProGrappler Provides a brief description of the ProGrappler, and displays the copyright notice and ProGrappler Version # on screen.
- Troubleshooting Displays common incompatibilities between certain combinations of hardware and software and methods of resolving them.

2."File" Menu

- Set Values...When selected, a Dialog Box appears with the following selections (each affect the file as a whole):
 - Bell Allows Bell (Control-G) command to be sent to printer.
 - Linefeed When selected, automatically appends a linefeed after every carriage return. When unselected, linefeed must be generated by software.
 - 3. Bit8 When selected, allows the eighth (high order) bit to be sent to the printer. When unselected, prevents the eighth bit from being sent to the printer. Some printers use the eighth bit to set an alternate character set for special print formatting such as italics and block graphics. The standard character set may not be available when Bit 8 is selected.
 - 4. Hold When selected, the values entered in the Format, Style, and Size Menus are held (or "fixed") and are automatically set the next time you turn on your ProGrappler. When unselected, the normal (default) values are used.

NOTE All special settings are lost when power is turned off.

SECTION B: PROGRAPPLER SCREEN MENUS

- Video When selected, text sent to the printer is also sent to the screen. When unselected, text is only sent to the printer.
- 6. Transparent When selected, the ProGrappler operates as a normal ("dumb") printer controller and forwards all print commands directly to the printer. When unselected, the ProGrappler operates as an "intelligent" printer controller and interprets all (Control-I) commands to the printer.
- 7. Color Selects the ribbon color to be used for printing:
 0. Black 1. Red 2. Blue 3. Yellow
- 8. Control Character Selects the control character recognized by the ProGrappler for print commands. Use "I" when using Applesoft BASIC, DOS 3.3, ProDos, ProDos 16, PASCAL 1.1, or Integer BASIC. Use "Y" when using PASCAL 1.0, or CP/M.

1.1 2.Y

- Text Dump 80 Prints from an 80 column wide screen (for Apple Ile systems using an Apple 80 column board, or for an Apple IIGS in 80 column mode).
- 3. **Text Dump 40** Prints from standard 40 column wide screen.
- Text Dump 1 & 2 Prints two 40 column text pages sideby-side (page 1 on the left, page 2 on the right).
- Form Feed Sends a "top-of-form" command to the printer each time this command is issued. This advances the paper to the next page.
- 6. Print Test Prints a set of characters seven times.
- 7. **Quit** Returns you to where you were in the program just prior to calling the Menu Bar.
- 3. "Format" Menu
- Page Set-up...A Dialog Box appears with the following selections:

1.	Left Margin =	Sets the left margin, as
	measured in spaces from	the left edge of the paper.
	User may enter any numb	er desired (within range of the
	printer).	

Right Margin = _____ Sets the right margin to the number of spaces entered here, as measured from the left edge of the paper. A carriage return is generated at the first space after the right margin setting, but before the end of the line if set by the Line Length command. This helps to prevent words

Section B: PROGRAPPLER Screen Menus, cont.

from being split (this is often called "wordwrap"). A value of "Ø" disables this command.

- 3. Line Length = ______ Sets the length of a line, as measured in characters from the left edge of the paper (not the left margin). A carriage return is generated after the last character or space of the line as specified (except when a Right Margin is set see Right Margin preceding). Text is not echoed to the screen during printing when this command is selected. Line Length should be selected before Right Margin. A value of "Ø" disables the carriage return. The carriage return must be provided by your Apple program when Ø is selected.
- I. Page Length = _____ Sets the number of lines on the page. The printer generates six (6) line feeds after the last line printed. This allows the perforation between pages to be automatically skipped if the number of lines is set properly. A value of "Ø" disables the automatic six line feeds.
- 5. **Lines/Inch** = _____ Sets the number of lines per inch according to the following selections:

1. 6 2.8

4. "Size" Menu

The following commands provide a selection of text sizes to be printed. These sizes vary according to the printer you use.

- Expanded The text size selected is horizontally elongated by a factor of two.
- 2. Pica
- Elite
- 4. Condensed

5. "Style" Menu

- 1. Draft Sets the printer into draft mode.
- Double-Strike The printer emphasizes text by printing each line twice (two separate passes). This creates a Bold look.
- Emphasized The printer emphasizes text by striking each dot twice during a single pass. The second dot is slightly offset from the first dot, creating a Bold look to the text. This is usually the preferred way of creating Bold text.
- NLQ Text is printed using "Near Letter Quality" printing.

Section B: ProGrappler Screen Menus, cont.

- Headline Text is printed using Expanded and Emphasized features. This is useful for headlines and other unique text applications.
- 6. **Proportional** Text is printed with a proportional style type.
- Underline Each character is underlined when printed.
- 8. Italic Each character is italicized when printed.
- 9. **Sub-Script** Each character is sub-scripted when printed.
- 10. **Super-Script** Each character is super-scripted when printed.

NOTE: The ProGrappler cannot generate typestyles not available with your particular printer.

6. "Graphic" Menu

Provides selections for printing graphics. Unlike text commands, which remain in effect until cancelled, you must select options each time you want a screen dump.

Before doing anything else, set the proper screen type for your picture. If you are unsure of your correct screen type, try your best guess and then select the WINDOW SET option from the GRAPHIC menu. If your picture is displayed, then you have selected the correct screen type. If something other than your complete picture is displayed, then return to the SCREEN TYPE option and try again. (Examples of screen types are Hi-Res, Super Hi-Res, etc.)

- 1. **Print** Causes the printer to start printing the graphics you currently have in the Hi-Res screen memory.
- Screen Type...A Dialog Box appears providing the following selections:
 - Mix Text and Graphics⁴ Prints the graphics screen plus the four-line text window beneath it. The printing begins 20 spaces from the left edge of the paper.
 - Page 1 Prints the Hi-Res graphics image from Page
 Each white screen dot is printed as a black dot.
 - 3. **Page 2** Prints the Hi-Res graphics image from Page 2 instead of Page 1.

graphics image.

- Side-By-Side⁵ Prints both Hi-Res graphics images (Page 1 on the left, Page 2 on the right).
 - Double Hi-Res⁶ Prints the Double Hi-Res
- Super HI-Res Prints a graphics image using the 320 x 200 or 640 x 200 dot screen memory. Only available from the Apple IIGS.
- 3. **Invert** Prints the "inverse" image as seen on the screen. Normally, white dots on the screen print as black dots on paper. This results in an image which looks like a photographic negative. The Invert command produces an image much like a photograph, where the black portions on the screen print as black on paper.
- Rotate⁷ Prints the graphic screen image rotated 90 degrees clockwise.
- Color When selected, prints a color graphics image as defined by the colors in the image itself. When unselected, prints in black and white.

When printing color, be aware that your printer cannot reproduce all of the over 4000 colors that the IIGS can display. For this reason, certain colors appearing different on the screen may appear the same on paper. (For example, light brown and deep orange may appear the same color when printed.)

- Hi-Density Prints an image using the printers' emphasized print mode.
- 7. Aspect Ratio...A Dialog Box appears providing a selection from 1 to 6.
- Page Position...A Dialog Box appears providing a choice of positions:
 - 1. Center: Narrow Carriage Prints the image centered on a 8 1/2 " carriage.
 - 2. Center: Wide Carriage Prints the image centered on a 14" carriage. Be sure your printer has a wide carriage.
 - Left Margin When selected, prints image using the Left Margin set in the Format menu. When unselected, prints image centered on an 8 1/2" carriage.

Section B: ProGrappier Screen Menus, cont.

⁴ Cannot be used with Rotate, Double-Size, or Left Margin options.

⁵ Cannot be used with Rotate or Double-Size options.

⁶ This is a special Apple IIIe (Rev B or later) option. It is not available with Apple II or II+. Cannot be used with Rotate or Double-Size options.

Only Hi-Res graphics can be rotated. Text cannot be rotated.

Section B: ProGrappler Screen Menus, cont.

- Enlargement...A Dialog Box appears providing a choice of enlargements of the printed screen image:
 - Double Size Prints the image with four dots for every screen dot (two in the vertical direction and two in the horizontal direction). This results in an image twice the normal size.
 - Custom Size Prints the image using "X" dots for each screen dot in the horizontal direction (XMAG), and "Y" dots for each screen dot in the vertical direction (YMAG). Values of 1 thru 6 may be used:

 XMAG
 YMAG
- 10. Window Set Allows you to print a portion of your image by setting a window over the part you want printed. When selected, your screen image is displayed temporarily with a small box located near the top left corner of the screen.

First, position the box with the arrow keys such that the top left corner of this box aligns with the top left corner of the desired window. Then hit (Return) to set this position. Next, position the lower right corner of the box such that it aligns with the lower right corner of the desired window. Again, use the arrow keys. You now see a window which contains the image you will print. Then hit (Return) to set this position. If you want to make changes at this point, repeat step10 until you are satisfied, then print.

If you are using a mouse, move the window to the top left corner of the area you want to print. Hold down the mouse button and drag to the lower right corner of the area you want to print.

SECTION C USING THE PROGRAPPLER KEYBOARD COMMANDS (For Apple IIGS, Ile and II+)

In order to give the ProGrappler a Keyboard command the cursor must be visible on your computer screen. If you are inside a program, first Exit your program by pressing the (CTRL-RESET) keys simultaneously. This should produce a cursor, at which you can enter the appropriate commands. (A few programs will not allow this, and so cannot be used with the ProGrappler features.) The basic procedure is as follows:

- 1. Turn ON the ProGrappler.
- 2. Give the Keyboard Command.
- 3. Turn OFF the ProGrappler.

TO TURN PROGRAPPLER ON:

If you are using Applesoft BASIC, type: PR#1 after the "]" prompt, then hit (Return).

If you are using CPM, enter: (Control-P).

TO TURN PROGRAPPLER OFF:

If you are using Applesoft BASIC, type: PR#Ø after the "]" prompt, then hit (Return).

If you are using CP/M, enter: (Control-P) again.

Once the ProGrappler is turned ON, you can give a command by using the CTRL key on your keyboard along with the 'l' key, followed by specific sequences of characters. The (Control-I) commands use mnemonics such as GR for rotate. To enter a (Control-I) command, you would first turn ON the ProGrappler (see above). Then, press down on the CTRL key and continue to hold it down as you type the letter 'l'. Release the CTRL key, then type 'GR'. The mnemonics for each command are listed under "Section D: ProGrappler Commands." After the command is executed, turn OFF the ProGrappler.

NOTE: Commands can also be entered as part of a PRINT statement which executes from within a program. PRINT statements are for experienced users and programmers. A list of the PRINT statements is included under "Section E: ProGrappler Commands."

Any command can be entered using (Control-I). The (Control-I) commands maintain total compatibility with software using the existing Grappler+ commands.

Section C: Keyboard Commands, continued.

Using Control-I Commands

A (Control-I) is used for Applesoft, Integer BASIC, ProDos, ProDos 16, DOS 3.3, or PASCAL1.1. A (Control-Y) followed by a "function-specific" mnemonic is used for PASCAL 1.0 CP/M.

NOTE: We assume the use of (Control-I) commands throughout this manual. Be sure to substitute "Y" for "I" if you are using PASCAL1.0 or CP/M.

Enter (Control-I) commands by the following simple procedure:

- While holding down the (Control) key, type the letter "I", then release the (Control) key. This is what is meant by (Control-I).
- Now type whatever follows the "i", such as "G" for graphic screen dump.
- 3. Press (Return).

Stringing (Control-IG) Commands Together

single command by adding on the "function-specific" part of each command to the first command. Only graphics commands may be strung together.

Example: To print an inverted and rotated color image, the entry looks like this: (Control-IGCIR), where "IG" activates the

graphics mode, "C" prints a color image, "I" inverts the image,

Several (Control-IG) commands may be executed with a

and "R" rotates the image. Using "PRINT" Statements

The use of PRINT statements usually requires some knowledge of BASIC programming. Therefore no attempt is made to explain the details. A list of PRINT statements are provided in "Section D: ProGrappler Commands" for those who wish to use them.

SECTION D: PROGRAPPLER COMMANDS

Menu names are listed below, along with the equivalent (Control-I) command, and PRINT statement. A brief description of each command is also provided. If you need more detail about a particular command, please refer to the description provided in the appropriate section: Pull-down Menus or Keyboard Commands.

General Commands

General Commands						
Function Nam	ne (Control-I)	PRINT <u>Statement⁸</u>				
Bell	(Control-IB)	?CHR\$(9);"B"				
	Allows Bell (Control-G) command to b					
	the printer.					
	(Control-IC)	?CHR\$(9);"C"				
	Cancels the Bell command					
Bit8	(Control-IH)	?CHR\$(9);"H"				
	Allows Bit 8 to be sent to printer.	, , ,				
	(Control-IX)	?CHR\$(9);"X"				
	Cancels Bit 8.	. ,				
Hold	(Control-IFA)	?CHR\$(9);"FA"				
	Retains current values during initializa	ation of				
	printer port.					
	(Control-IQA)	?CHR\$(9);"QA"				
	Restores to default values upon initia	lization				
	of printer port.					
Access Menu	ıs (Control-IFM)	?CHR\$(9);"FM"				
	Displays the Manu Bar.					
Video	(Control-II)	?CHR\$(9);"I"				
	Echo's printer output to screen.					
	(Control-IQV)	?CHR\$(9);"QV"				
	Cancel's printer echo.					
Transparent	(Control-IT)	?CHR\$(9);"T"				
	Instructs ProGrappier to ignore all frt	her (Control-I) commands				
	until re-initialized. This is the "Transp	arent" mode.				
Transparent	(Control-IZ)	?CHR\$(9);"Z"				
	This command may be used in place	of the				
	command above.					
Trouble-						
shooting	(Control-IFT)	?CHR\$(9);"FT"				
	Prints Troubleshooting information to	the printer.				
Print Test	(Control-IFS)	?CHR\$(9);"FS"				
	Prints the entire alpha-numeric chara	cter set.				

23

Similiar to Printer Self-Test.

⁸A "?" is used in place of "PRINT."

Section D: Pro	Grappier Commands, co	nt.		Section D: Pro	Grapp	ler Commands, <i>c</i> c	ont.
Text Formattin	g And Style Commands			Expanded		(Control-InMP)	?CHR\$(9);"nMP"
					Sets pri	nter pitch (characters per i	nch) to "n", where:
<u>Menu Item</u>	(Control-I)	PRINT Statement			n=1	Pica	
					n=2	Einte	
Italic	(Control-IWI)	d?CHR\$(9) ;"WI"			n=3	Condensed	
	Puts printer in Italic mode.				n=4	Extended Pica	
	(Control-IQI)	?CHR\$(9);"QI"	•		n=5	Extended Elite	
	Cancels Italic command				n=6	Extended Condensed	1
Draft	(Control-IWD)	?CHR\$(9);"WD"		Proportional		(Control-IWR)	?CHR\$(9);"WR"
	Puts printer in Draft mode.				Sets pri	·	Not all printers support this
NLQ	(Control-IWN)	?CHR\$(9); "WN"	•		mode.	,	,
	Puts printer in Near Letter Quality	mode.				(Control-IQR)	?CHR\$(9);"QR"
	(Control-IQN)	?CHR\$(9);"QN"			Cancels	Proportional command.	
	Cancels NLQ command			Right Margin		(Control-InR)	?CHR\$(9);"nR"
Double-Strike	(Control-IWL)	?CHR\$(9); "WL"			Sets the	right margin to "n" dharad	• • • •
	Puts printer in Double-Strike mode					•	ne following "n" characters.
	(Control-IQL)	?CHR\$(9);"QL"			_	s Word Wrap.	o lollotting 11 drafactors.
	Cancels Double-Strike command.			Text Dump 40		(Control-IS)	?CHR\$(9);"S"
Emphasized	(Control-IWE)	?CHR\$(9);"WE"		Text builty 40		· ·	on to the printer. Position is
•	Puts printer in Emphasized mode.	• • •				es from the left edge of the	•
	(Control-IQE)	?CHR\$(9);"QE"				column text display board	
	Cancels Emphasized command.			Text Dump 80		(Control-I8S)	?CHR\$(9);"8S"
Color	(Control-InMC)	?CHR\$(9);"nMC"		Text Dullip 00		n 80 column screen to the	
	Sets the ribbon color, where:	* **		Subscript	rnnsa	(Control-IWB)	?CHR\$(9);"WB"
	n=0 Black			Subscript	Sate na	nter to Subscript mode.	Clina(a), WD
	n=1 Red			Cuparacrint	Ses pri	(Control-IWP)	?CHR\$(9);"WP"
	n=2 Blue			Superscript	Coto ori	,	TOTING(9); WP
	n=3 Yellow				seis pri	nter to Superscript mode.	20HB¢(0)-"06"
Headline	(Control-IWH)	?CHR\$(9);"WH"			Canack	(Control-IQS)	?CHR\$(9);"QS"
	Puts the printer into Headline mod				Carices	s both Subscript and Sup	arscript commands.
	(Control-IQH)	?CHR\$(9);"QH"		Form Feed		(Control-	OCHD¢(O)."ED"
	Cancels Headline command.			rom reed	Canala a	(Control-IFP)	?CHR\$(9);"FP"
Left Margin	(Control-InL)	?CHR\$(9);"nL"		Underline On	Seriosa	Form Feed to the printer.	OCHECO - WALLE
	Sets left margin to "n" spaces from			Underline On	Code a d	(Control-IWU)	?CHR\$(9);"WU"
Line Feed	(Control-IA)	?CHR\$(9);"A"			Sets pni	nter to Underline mode.	001100(0).!!01!!!
Zillo i dod	Appends a Line Feed to each Can	* **			0	(Control-IQU)	?CHR\$(9);"QU"
	(Control-IK)	?CHR\$(9);"K"		About Due	Canceis	: Underline command.	
	Cancels Line Feed command.			About Pro-		(O t 1 1)()	001104(0) 111(11
Line Length	(Control-InN)	?CHR\$(9);"nN"		Grappier	Dásta	(Control-IV)	?CHR\$(9);"V"
Line Long	Sets Line Length to "n" characters					ersion of ProGrappler ROM	n to the printer.
	Return. A value of "0" disables line	-		T D	Inisisn	ot echoed to the screen.	
Lines/Inch	(Control-InML)	?CHR\$(9);"nML"		Text Dump		(0 1 - 1 100)	0.01104(0) 110011
Linesimon	Sets the number of lines per inch,		٠	1 & 2	D:	(Control-I2S)	?CHR\$(9);"2S"
	n=6	Six lines/inch				O-column Text Pages 1 an	•
	n=8	Eight lines/inch				on the left, Page 2 on the i	ight). Not compatible
Page Length	(Control-InP)	?CHR\$(9);"nP"			with 80 c	column output boards.	
rage Length	Sets the page length to "n" lines. S			Control		(Control-I	001104(0) 01104(0=
announted offers		-		Character	~ !	Control-Y)	?CHR\$(9);CHR\$(25)
	"n" lines are printed. A value of "Ø"	ADALAGO			•	s the Control character fro	•
this command.						ould be taken to avoid usin	ng a character already in
					use by y	our printer.	

Section D: ProGrappler Commands, cont. (Control-Y Control Character Control-I) ?CHR\$(25);CHR\$(9) Changes the Control character from "Y" back to "I". Graphics Commands (Control-I) Menu Item PRINT Statement ?CHR\$(9);"G" Page 1 (Control-IG) Prints Hi-Res graphics Page 1 to the printer. Additional commands which may follow it (using a comma as the delimiter) indude: Color (Control-IGC) ?CHR\$(9);"GC" Prints a color image to the printer. This option is available for both Normal Hi-Res and Double Hi-Res images. **Double Hi-Res** (Control-IGe) ?CHR\$(9);"Ge" Prints a Double Hi-Res image to the printer. All options are available in this mode. Super-Hi Res (Control-IGA) ?CHR\$(9);"GA" Prints an image with a resolution of 320 x 200 or 640 x 200 pixels to the printer. Only available on the Apple IIGS. **Double Size** (Control-IGD) ?CHR\$(9);"GD" Prints a double-size image to the printer. Each dot is printed with four dots (XMAG=2, YMAG=2). **Hi-Density** (Control-IGE) ?CHR\$(9);"GE" Prints an image using the printers' emphasized print mode. Invert (Control-IGI) ?CHR\$(9);"GI" A black screen dot is printed as a black dot. Left Margin (Control-IGL) ?CHR\$(9);"GL" Prints graphics using the left margin set in the "LEFT = n" command. When not set, prints image centered on a narrow carriage (same as for "+GRAPH"). (Control-IG2) Page 2 ?CHR\$(9);"G2" Prints the graphics image stored in Page 2. **Aspect Ratio** (Control-IG*n) ?CHR\$(9);"G*n" Prints the graphics image with a width to height of "n" (n =/to6). Rotate (Control-IGR) ?CHR\$(9);"GR" Prints a graphics image rotated 90 degrees clockwise. Center: Wide Carriage (Control-IGG) ?CHR\$(9);"GG"

Section D: ProGrappler Commands, cont.

Print Side-	(Control-IGS)	?CHR\$(9);"GS"			
by-Side	Prints graphics images from Page 1 and Page 2 side by side to the printer. Cannot be used with Rotate or Double-Size				
	options.Mix Text &				
Graphics	(Control-IGM) Prints the graphics image and the printer.	?CHR\$(9);"GM" e 4 line text window to the			

Default ParametersDefault parameters are those commands which are

automatically set when you turn on your system.

The following is a list of the default parameters as set by the factors:

factory:

Command Applesoft BASIC PASCAL & CP/M

Left Margin Ø Ø

(Control-IGWn)

(Control-IGXn)

(Control-IGYn)

direction (n = integer from 1 to 6).

direction (n = integer from 1 to 6).

Window Set

XMAG

YMAG

Print Side-

Prints a graphics image centered on a wide (14") carriage.

Prints a graphics image magnified by "n" in the horizontal (X)

Prints a graphics image magnified by "n" in the vertical (Y)

Prints that portion of an image falling inside a box (n = X1, X2, Y1, Y2) whose upper left coordinate is X2, Y2.

?CHR\$(9);"GWn"

?CHR\$(9);"GXn"

?CHR\$(9);"GYn"

?CHR\$(9);"GS"

TROUBLESHOOTING

The following is intended to provide a guide to the most common problems you might encounter when installing or using the ProGrappler. Most of the problems you might encounter are incompatibilities due to certain combinations of hardware and software.

If you are using... Appleworks version 1.0 or 1.1 and the problem is ...
An "80N" appears in the upper left corner of all printouts, or...
Strange text formatting appears, then...

The Solution Is...

Obtain an upgrade to version 1.2 or greater from your Apple dealer. Then enter the Interface Card section in the Appleworks menu and change the code from (Control-I 80N) to (Control-I ØN).

If you are using...
Appleworks version 1.2,

An "80N" appears in the upper left corner of all printouts, or...
Strange text formatting appears, then...

and the problem is ...

The Solution Is...

1.3, or 2.0

Graph

Printer

Enter the Interface Card section in the Appleworks menu and follow the same procedure as above.

If you are using...
PFS:Write or PFS:

and the problem is...
The printer prints garbage when you merge a graph with a text file, then...

The Solution Is...

Set the ProGrappler to Transparent mode (or enter the *P09,84* command in the PFS software). Then enter the name of your printer in place of "ProGrappler" using the "Print Options" command in the installation section of the PFS software.

If you are using... Wordstar (Micro-Pro) with a Letter Quality

and the problem is...
You get garbage when you print, then...

The Solution Is...

Set the Transparent mode in the ProGrappler. Insert a (Control-IT) in the printer installation area of your program if allowed.

If you are using... and the problem is...

MousePaint with ProDos You get garbage when printing a (Apple Computer Company) graphics picture, then...

The Solution Is...

Obtain a patch program called "MousePrint" and instructions from AHWARE Software Company, Danville, CA (415) 284-5180.

If you are using... and the problem is...

Homeword (Sierra On-Line) You get no printing, or your software hangs, then...

The Solution Is ...

Change the selection from ProGrappler to "Other" in the installation program of Homeword.

If you are using...
Dollars and Sense
(Monogram Software)

and the problem is...
Graphics cannot be printed from within the program, then...

The Solution Is...

First exit the program to the Operating System level. Then boot up "System Master 3.3" and load the Dollars and Sense graphics diskette. Then use the ProGrappler "BLOAD" command described in Appendix B of this manual.

If you are using... VisiPlot or VisiTrend, Version 1.0 or 1.1 (VisiCorp)

and the problem is...
The program will not do a screen dump, then...

The Solution Is...

First, save your graphics to a data disk. Then use the ProGrappler "BLOAD" command described in Appendix B of this manual.

If you are using... Paintworks Plus and the problem is...

You can't print anything, then...

The Solution Is...

(Activision)

Copy the file "Basic.System" from the Apple IIGS system disk to the Paintworks disk. Then use the newly configured Paintworks disk to install the ProGrappler following the normal startup procedure in this ProGrappler manual. You can then use the ProGrappler CDA to print selected graphics from Paintworks Plus.

If you are using...

PASCAL 1.Ø or CP/M in any application...

The Solution Is...

- PASCAL I.Ø AND CP/M use (CONTROL-I) to represent a horizontal tab. If you are listing a file which contains tabs, first set the tabs according to your printer manual. Then list the file.
- 2. PASCAL 1.Ø and CP/M use one of the I/O RAM locations to pass the output character. Since the ProGrappler uses all available locations for its variables, the Right Margin function is not available to maintain compatibility with existing software.

APPENDIX A: RUNNING TEST PROGRAMS

The following programs are for the experienced user, and allow testing the graphics capabilities of the ProGrappler.

Applesoft Basic

- 5 TEXT
- 1Ø HOME
- 2Ø PRINT "ENTER THE SLOT YOUR PROGRAPPLER IS IN AND"
- 3Ø INPUT "HIT THE RETURN KEY:":S
- 5Ø HGR:REM CLEAR HI-RES PAGE 1
- 6Ø HCOLOR=3:REM SET COLOR TO WHITE
- 7Ø POKE 49234,Ø:REM SWITCH TO FULL-SCREEN GRAPHICS
- 8Ø HPLOT Ø,Ø TO 279,Ø TO 279,19Ø TO Ø,19Ø TO Ø,Ø:REM DRAWS RECTANGLE
- 9Ø FOR X=Ø TO 279 STEP 9:HPLOT X,Ø TO X,19Ø:REM PLOT VERTICAL LINES
- 1ØØ NEXTX
- 11Ø FOR Y=Ø TO 19Ø STEP 5:HPLOT 279, Y TO Ø,Y:REM PLOT HORIZONTAL LINES
- 12Ø NEXTY
- 13Ø PRINT CHR\$(4);"PR#";S:REM TURNS ON PRO-GRAPPER
- 14Ø PRINT CHR\$(9);"G":REM DUMP HI-RES PAGE 1 NORMAL
- 15Ø PRINT CHR\$(4);"PR#Ø": REM TURNS OFF PRO-GRAPPLER
- 16Ø TEXT:REM HOME CURSOR
- 999 END

If you do not use DOS, substitute the following for lines 130 and 150:

- 13Ø PR#S
- 15Ø PR#Ø

Line 14Ø allows you to experiment with different options. Try changing the function-specific part of the command in the PRINT statement. For example, substitute "GI" or "GDR" for "G".

```
BEGIN
PASCAL: Example #1
                                                               WRITE("Enter options:');
Appendix A - Running Test Programs
                                                               READLN(options);
FOR PASCAL USER:
                                                               REWRITE(prnt, 'PRINTER:'):
  PROGRAM DEMO:
                                                               WRITELN(prnt, CHR$(25), 'G', options);
  USES TURTLE GRAPHICS, APPLESTUF;
                                                               CLOSE(prnt);
  VAR ANGLE, DISTANCE: INTEGER
                                                             END
       PRINT:TEXT
                                                             BEGIN
       BEGIN
                                                               INITTURTLE
         ANGLE:=8Ø:
                                                             REPEAT
         INITTURTLE:
                                                             TEXTMODE
         PENCOLOR(WHITE);
                                                             WRITELN ('Enter picture name(specify drive):)
         FOR DISTANCE:= 1 to 99 DO
                                                             (An example of an entry would be:
                          BEGIN
                                                               #5:Picture, Foto
                           MOVE(2*DISTANCE);
                                                             where Picture. Foto is a picture on Drive#2.)
                           TURN(ANGLE);
                                                             READLN(fname);
                          END
                                                             GRAFMODE;
         REWRITE(PRINT, 'PRINTER:')
                                                             Bload (fname):
         WRITELN(PRINT, CHR$(25), 'G');
                                                             REPEAT UNTIL KEYPRESS:(wait until key is pressed)
        END
                                                             READ(KEYBOARD,ch);clear keyboard
                                                             TEXTMODE:
PASCAL - EXAMPLE #2
                                                             Print
                                                                      Picture;
This program demonstrates how to load a picture which has
                                                             WRITE('Print more pictures?);
been saved to disk using a BLOCKWRITE command.
                                                             READLN(ch);
                                                             UNTiL(ch='N') or (ch='n');
PROGRAM LOAD PIC:
                                                             END
USES TURTLEGRAPHICS, APPLESTUF;
CONST Hi-Res ____ Page ____ 1 = 8192:
VAR Disk
              Block: RECORD CASE BOOLEAN OF TRUE:
                                                             APPENDIX B: PRINT GRAPHIC SAVED TO
                    (Intpart:INTEGER):
                                                             DISK
                    FALSE;(Ptrpart:Y INTEGER);
                                                             The following Applesoft BASIC programs are for the
END:
                                                             experienced user. They allow you to print graphics (from one
  ch:CHAR
                                                             of the popular graphics programs) which have been saved to
fname:STRING;
                                                             disk.
  prnt:TEXT;
                                                             Example # 1
PROCEDURE Bload (Filename:STRING):
                                                                     S = 1^9
                                                                5
VAR io: INTEGER;
                                                               1Ø
                                                                     HOME
  f:FILE:
                                                               2Ø
                                                                     D$=CHR$(4):REM CTRL-D for Apple DOS
BEGIN
                                                                     PRINT "ENTER THE NAME OF THE GRAPH:"
                                                               4Ø
           BLOCK.Intpart;=Hi-Res Page 1;
  DISK
                                                                     INPUT N$
                                                               5Ø
  RESET(f,Filename);
                                                               6Ø
                                                                     HGR:REM Clear Hi-Res Page 1
  io:=BLOCKREAD(f,Disk Block Ptpart Y,16);
                                                                     PRINT D$:"BLOAD";N$:",A$2ØØØ":REM Load
                                                               7Ø
  CLOSE(f,LOCK);
                                                                     Picture
END:
                                                               8Ø
                                                                     VTAB 22
PROCEDURE Print
                     Picture;
VAR options: STRING:
```

⁹If your ProGrappler is not in Slot #1, change this to read the correct slot.

9Ø PRINT "ENTER OPTIONS (D,I,R,L,E,NORMAL);"

1ØØ INPUT A\$

1Ø5 IF LEFT\$(A\$,1)="N" THEN A\$="":REM If normal, then no options.

11Ø PRINT D\$;"PR#n";S:REM Turns PRO-GRAPPLER on

12Ø PRINT I\$;"G";A\$: REM Dump Hi-Res Page 1 with options

13Ø PRINT D\$:"PR#Ø":REM Turns PRO-GRAPPLER off

14Ø TEXT:HOME 999 END

Example #2

Enter a (Control-D) between the quotes in line 3Ø. Enter a (Control-I) between the quotes in line 4Ø.

5 S=1

1Ø CALL-936:REM Home Cursor

2Ø DIM N\$(3Ø):DIM A\$(1Ø) 3Ø D\$=CHR\$(4)

4Ø I\$=CHR\$(9)

5Ø PRINT "ENTER THE NAME OF THE GRAPH:"
6Ø INPUT N\$

7Ø PRINT D\$:"BLOAD";N\$;",A\$2ØØØ":REM Load

Picture into Hi-Res Page 1

8Ø PRINT "ENTER OPTIONS (D,I,R,E,L NORMAL):"

9Ø INPUT A\$
1ØØ PRINT D\$

1ØØ PRINT D\$;"PR#n";S:REM Turns ProGrappler on 11Ø PRINT I\$;"G";A\$:REM Dump Hi-Res Page 1 with

options
12Ø PRINT D\$;"PR#Ø":REM Turns ProGrappler off

13Ø TEXT:CALL-936:REM Home Cursor

999 END

APPENDIX C: LOADING DUAL HI-RES PAGES

You must load a picture file into Hi-Res Pages 1 and 2 in order to use the DUAL HI-RES command.

From the Keyboard

For Hi-Res Page 1, enter:

BLOAD filename, A\$2ØØØ For Hi-Res Page 2, enter:

BLOAD filename, A\$4ØØØ

From within a Program

For Hi-Res Page 1, enter:

PRINT CHR\$(4);"BLOAD filename,A\$2ØØØ" For Hi-Res Page 2, enter: PRINT CHR\$(4):"BLOAD filename. A\$4ØØØ"

These DOS commands must precede the line containing the PR#n which turns the ProGrappler on.

Sample Program

The following program loads two Hi-Res binary files (pictures): GRAPH 1 is loaded into Page 1, GRAPH 2 is loaded into Page 2.

They are then printed to the printer using the DUAL HI-RES command.

10 PRINT CHR\$(4); "BLOAD GRAPH 1,A\$2ØØØ" 20 PRINT CH4\$(4); "BLOAD GRAPH 2,A\$4ØØØ" 30 PR#1 40 PRINT CHR\$(9); "GS" 60 PR#0:END

APPENDIX D: SIMULATING A CHART RECORDER

A chart recorder prints a continuous graph on a roll of paper. If your chart might exceed a single page on your printer, you can simulate a chart recorder by printing successive pages together.

The following program loads binary graph files (GRAPH 1 into Hi-Res Page 1, GRAPH 2 into Hi-Res Page 2) and prints one right after the other without the spaces between them (the ROTATE command may also be used with this program):

10 PRINT CHR\$(4);"BLOAD GRAPH 1,A\$2ØØØ"
20 PRINT CHR\$(4);"BLOAD GRAPH 2,A\$4ØØØ"
30 PR#1
40 PRINT CHR\$(9);"GR"
50 PRINT CHR\$(9);"G2R"
60 PR#0:END

APPENDIX E - ROUTINES FOR ADVANCED PROGRAMMERS

The following ProGrappler commands are provided for the benefit of advanced (assembly language) programmers:

CTRL-IUA Jump to the user routine starting at \$300.

This bypasses the ProGrappler firmware. The

Accumulator contains the output character. The user
should perform this operation when finished:

PLA TAY PLA TAX LDA \$478 PLP RTS

CTRL-I1U Jump to the user routine starting at \$DØØØ, Bank A of a RAM card in Slot # Ø.

The ProGrappler enables the RAM card prior to the Jump instruction. As with the CTRL-IU, the Accumulator contains the output character. The user should perform this operation when finished:

LDA \$CØ81 PLA TAY PLA TAX LDA \$478 PLP RTS

APPENDIX F: TRANSPARENT MODE

If you have a program (such as Wordstar) which uses the same control codes as the ProGrappler, you need to make the ProGrappler transparent to that program. The Transparent Mode causes the ProGrappler to pass all commands on to the printer just like a standard parallel printer controller would.

You can activate the Transparent Mode with a Control code¹⁰. It remains in effect until you turn the ProGrappler off, or until you reset the computer.

To activate the Transparent Mode

Type PR#1, enter (Control-IT), then hit (Return). This causes the ProGrappler to ignore all subsequent control codes until the ProGrappler is turned off with a PR#Ø, or when the computer is reset.

NOTE: Characters sent to the printer, either from a program or from the keyboard, are not echoed to the screen when in the Transparent Mode.

To de-activate the Transparent Mode:

Type PR#0, then hit (Return), or reset the computer by entering (Control - ♂ - Reset).

APPENDIX G: MEMORY LOCATIONS AND CUSTOM DRIVERS

Memory Locations

The ProGrappler uses those RAM locations set aside for its particular slot and the slot scratchpad area common to all slots. The ROM is turned on using the standard ROM expansion protocol and resides in the locations \$C800 to \$CFFF. The entry points and the various RAM variables are listed below (N = slot number)

Cold Entry	\$CNØØ
Warm Entry	\$CNØ2
Left Margin	\$478 + \$ØN
Right Margin	\$678 + \$ØN
Line Length	\$578 + \$ØN
Page Length	\$5F8 + \$ØN
Character Count	\$4F8 + \$ØN
Line Counter	\$6F8 + \$ØN
Current Cmd. Char.	\$778 + \$ØN
Text Flags	\$7F8 + \$ØN

Text Flag Bit Representations:

Bit 7 = Output high order bit Bit 6 = Video turned on Bit 5 = LF after CR Bit 4 = Bell On Bit Ø-3 = Reversed

Custom Drivers

If you are writing your own drivers, the following locations are used to access the card (Y = NO where N = slot #):

ADDRESS \$CØ8Ø,Y \$CØ81,Y	READ Status	WRITE Output Select bank of ROM
φυ 2 01,1		Select bank of HOM

¹⁰ You can also activate the Transparent Mode by setting the DIP switch as according to the settings indicated in Table 1 under *Transparent Mode*. To de activate the Transparent Mode using the DIP switch, first turn power OFF. Then remove the ProGrappler board and set the switch positions according to the settings indicated for your printer, then reset the computer.

APPENDIX H: PROGRAPPLER PIN ASSIGNMENTS

Table 3 lists the pin assignments for each connector on the ProGrappler cable. The 36 pin male Centronics printer connector is shown in Figure 3.

PROGRAPPLER HEADER	SIGNAL NAME	PRINTER	SIDE
1	Strobe	1	
2	Ground	19	
3	Data Bit 0	2	
4	Ground	20	
5	Data Bit 1	3	
6	Ground	21	
7	Data Bit 2	4	
8	Ground	22	
9	Data Bit 3	5	
10	Ground	23	
11	Data Bit 4	6	
12	Ground	24	
13	Data Bit 5	7	
14	Ground	25	
15	Data Bit 6	8	
16	Ground	26	
17	Data Bit 7	9	
18	Ground	27	
19	Acknowledge	10	
20	Ground	28	

Table 3. ProGrappler Pin Assignments

Busy

Ground

Select

Ground

Paper Empty

11

29

12

13

30

21

22

23

25

26




Figure 3

APPENDIX I: PRINTER COMPATIBLITY

Some printers do not have all of the commands which the ProGrappler provides. Table 4 shows the ProGrappler commands which are not supported by that printer.

PROGRAPPLER COMMANDS NOT SUPPORTED

NEC; C. ITOH	Unavailable Text Commands: Compressed, Super and Subscript.
Epson FX-80 and compatibles	Unavailable Text Commands: Compressed
Okidata	Unavailable Text Commands:

Table 4. ProGrappler commands not supported

Note that some printers are supported only in specific modes. The following chart indicates the modes supported by the ProGrappler:

PRINTER BROTHER	MODE SUPPORTED
TWINWRITER 2	DP Mode
BROTHER 2024L	DP Mode
BROTHER M-1509	Mode 1 (EPSON Mode)
CITIZEN MSP20/25	EPSON - FX
C. ITOH C - 310/15 P/R	Standard
C. ITOH 310 XP	EPSON
EPSON EX - 800/1000	EPSON
H.P. THINKJET	Alternate Mode (EPSON)
NEC PINWRITER P5	Standard

OKIDATA 290 SERIES	Standard (NOTE : Printer must be set to 7- bit data format by using MENU SELECT OPTIONS.)
OKIMATE 20	Standard
PANASONIC KX-P1091	Standard
STAR SD STAR SR, SG STAR NX	STAR STAR Standard (Using EPSON dip switch setting on ProGrappler.)

TOSHIBA (QUME)

Standard

TOSHIBA P351C

TOSHIBA P321

RADIO FREQUENCY INTERFERENCE

This equipment generates and uses radio frequency energy, and if not installed and used properly in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for class B computing device in accordance with the specifications in Subpart j of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a

residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1. Reorient the receiving antenna.
- Relocate the computer into a different outlet so that the computer and receiver are on different branch circuits.
- 3. Consult the dealer or an experienced radio/television technician for additional suggestions.
- 4. Obtain a copy of "How to Identify and Resolve Radio-TV Interference Problems" (Stock No. 004-000-00398-5) by the Federal Communications Commission. It may be ordered free of charge by writing to: U.S. Government Printing Office, Washington, D. C. 20402 and specifying the above title and its stock number.

Shielded cables must be used with this unit to meet compliance requirements of the FCC.

LIMITED WARRANTY

NOTES:

Every ProGrappler board is fully tested and checked for quality prior to shipment. It is warranted to be free from defects in materials and workmanship for a period of **one (1) year** from the date of purchase. During that time period, Orange Micro Inc. will, at no charge to the purchaser of record, repair or replace any defective unit returned to its Service Department in accordance with the following instructions:

NOTE: Do NOT return the ProGrappler to Orange Micro Inc. until you have received a Return Authorization number. Phone the Orange Micro Technical Support Department at 714/779-2772 to obtain a Return Authorization Number.

- Provide Orange Micro Inc. with: Model, Serial Number, Proof
 of Purchase with Date, Return Address, and preferred
 return shipping method. Enclose a clear description of the
 problem experienced and any sample printouts showing the
 problem. if possible.
- Ship in the original carton or securely packed in a cardboard carton with at least two inches of cushioned packing material on all sides. Mark the package "FRAGILE" and ship via UPS, Parcel Post, or Air Freight, insured and prepaid.

NOTE: Do not send COLLECT - collect shipments will be refused and returned to sender.

Orange Micro Inc. disclaims any liability to users of the ProGrappler for consequential damages of any kind arising from or connected with the use of the ProGrappler board.

This warranty is void in cases of misuse, abuse, abnormal conditions of operations or attempts to alter or modify the function of a part or assembly.

This limited warranty is in lieu of all other warranties expressed or implied, and no representative or other person is authorized to represent or assume for Orange Micro Inc. any warranty liability beyond that set forth herein.

This warranty gives you specific legal rights, and you may also have additional rights which vary from state to state. The warranty expressed herein applies only to the ProGrappler sold and used in the United States of America.