



Note: Most Taiwan/Hong Kong PCBs have two vias that have to be drilled out for proper operation.  
a) shorts D0 to Ucc (below 6821 bottom)  
b) shorts pin 19 of ZIF socket to EA2